Tent installation instructions

Tent 5m type Sp38

Name	No.	Picture	5 x 6	Extra 2 m	Extra 1 m
Tube dia. 38 mm (Φ) (1895 mm)	1		8	2	2
Tube dia. 38 mm (Φ) (1930 mm)	2	• •	21	7	
Tube dia. 38 mm (Φ) (930 mm)	3				7
Triple roof connector dia. 42 mm (Φ)	4		4		
Quad roof connector dia. 42 mm (Φ)	5		6	2	2
Corner foot	6		2		
Corner foot	7	S.F.	2		
Foot	8		4	2	2
Entrance foot	9		4		
Roof concentration dia. 25 mm (Φ) (320mm)	10		4	1	1
Peg 8x300mm	11	©	4		
Peg 6x180mm	12		12	2	2
Peg 4x180mm	13		42	6	6
String	14		4		
Screw M6x35	15		8	2	2
Screw M6x50	16		100	28	28
Entrance mounting bracket	18	\bigcirc	16		

Tent installation instructions

Tent 5m type Sp38


Triple connector econector A1 Image: connector da 42 mm A2 Image: connector da 42 mm A2 Image: connector A3 Image: connector A4 A1 A1 Vertical roof connector A4 A4 Image: connector I	Name	No.	Picture	5 x 6	Extra 2 m	Extra 1 m
(Φ) (110 ⁹) A2 A2 A2 A3 A2 A3 2 2 2 Triple peak roof connector dia. 42 mm (Φ) (140 ⁹) A3 A3 A3 2 1 1 Quad peak roof connector dia. 42 mm (Φ) (140 ⁹) A4 X X 2 1 1 Vertical rooft connector dia. 25 mm (Φ) (507mm) 50 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 51 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 52 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 52 4 1 1 Tube dia. 38 mm (Φ) (1185 mm) 53 4 4 4	Triple corner connector dia. 42 mm (Φ) (110 ⁰)	A1		4		
Quad peak roof connector dia. 42 mm (Φ) (140 ^Φ) A4 X 2 1 1 Vertical roof connector dia. 25 mm (Φ) (507mm) 50 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 51 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 51 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 52 1 1 1 Horizontal roof connector dia. 25 mm (Φ) 52 1 1 1 Tube dia. 38 mm (Φ) (1185 mm) 53 1 1 1	Quad corner connector dia. 42 mm (Φ) (110 ⁰)	A2	×	4	2	2
Vertical roofl connector dia. 25 mm (Φ) (507mm) 50 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 51 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 51 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 52 4 1 1 Tube dia. 38 mm (Φ) (1185 mm) 53 6 6 4 4	Triple peak roof connector dia. 42 mm (Φ) (140 ⁰)	AЗ		2		
dia. 25 mm (Φ) (507mm) 50 4 1 1 Horizontal roof connector 51 4 1 1 Horizontal roof connector 51 4 1 1 Horizontal roof connector 52 4 1 1 Horizontal roof connector 52 4 1 1 Horizontal roof connector 52 4 1 1 Tube dia. 38 mm (Φ) (1185 mm) 53 53 16 4 4 Tube dia. 38 mm (Φ) (1600 mm) 53 53 53 53 53 53	Quad peak roof connector dia. 42 mm (Φ) (140 ⁰)	A4		2	1	1
dia. 25 mm (Φ) 51 4 1 1 Horizontal roof connector dia. 25 mm (Φ) 52 4 1 1 Tube dia. 38 mm (Φ) (1185 mm) 53 6 6 4 4 4 Tube dia. 38 mm (Φ) (1600 mm) 53 6 6 6 6 6 6		50		4	1	1
dia. 25 mm (Φ) 52 4 1 1 Tube dia. 38 mm (Φ) (1185 mm) 53 6 6 4 4 4 Tube dia. 38 mm (Φ) (1600 mm) 6 6 6 6 6 6 6		51	1	4	1	1
Tube dia. 38 mm (Φ) (1165 mm)		52	r	4	1	1
Tube dia. 38 mm (Ф) (1600 mm) 54 • <	Tube dia. 38 mm (Φ) (1185 mm)	53	•	16	4	4
Image: Section of the section of th	Tube dia. 38 mm (Φ) (1600 mm)	54	•	6		

STEP 1

The tent should be deployed on the flat surface.


For the tents with the even length of the side eg. 8m, 10m, 12m, 20m, 30m,

Distribute the parts as pictured below. Connect all the dia. 38 mm (Φ) tubes with the connectors using the M6x50 screws.




For the tents with the uneven length of the side eg. 9m, 11m, 13m, 21m, 31m.....

Distribute the parts as pictured below. Connect all the dia. 38 mm (Φ) tubes with the connectors using the M6x50 screws.




STEP 2/a



Connect the brackets (51) and (52) using the M6x35 screws. Connect the obtained construction to the 2 lower part of connectors (4 or 5).

Using the vertical bracket (60) connect the horizontal bracket (10) to the previously assembled parts.




Fully assembled roof construction should look like on the picture above



3


STEP 3

Gently lift the tent on one side and mount the tube (1). The single hole in the pipe should be facing downwards. Next, lift the tent on the other side and mount the tube (1) there.




STEP 4

Mount the corner feet (6) diagonally (same applies to feet 7). On the sides of the tent mount the feet (8) and connect them to the tubes (2). For the tents with uneven length of the side, the one meter extension should be mounted in the third section. The feet (9) should be installed on the front and on the back of the construction and connected to the corner feet via tube (54). All the feet should be securely mounted to the ground.




STEP 5


Side panels should be mounted directly to the roof using the velcro stripes. Sides of the panels should be mounted using the elastic rubber with the ball.



The upper part of the entrance using the metal brackets (18) to the horizontal tube (51 and 52). The sides of the entrance should be mounted using the elastic rubber with the ball.



Mount the masking stripes. One of each of the four wider masking stripes should be installed on the each corner of the tent.



Fix the roof pulls on the corners of the tent using the (14) and (11) parts. All the lines should be tight.