# Namiot 4m typ P50

Name	No.	Picture	4 x 6	Extra 2 m	Extra 1 m
Tube dia. 50 mm (Φ) (1890 mm)	1		12	2	2
Tube dia. 38 mm (Φ) (1920 mm)	2	• • •	21	7	
Tube dia. 38 mm (Φ) (930 mm)	3				7
Triple roof connector dia. 54 mm (Φ)	4		4		
Quad roof connector dia. 54 mm (Φ)	5		4	2	2
Corner foot	6		2		
Corner foot	7	38	2		
Foot	8		4	2	2
Entrance foot	9		4		
Roof bracing dia. 25 mm (Φ) (320 mm)	10		4	1	1
Peg 8x300 mm	11	©—————————————————————————————————————	4		
Peg 6x180 mm	12		12	2	2
Peg 4x180 mm	13		42	6	6
Rope	14		4		
Screw M6x35	15		9	2	2
Screw M8x50	16		50	10	10
Screw M8x70	17		62	12	12
Loop to mount the entrance	18		12		
		<u></u>			

# Tent 4m type P50

Total motalidation motifications		rent 4m type r 50			
Name	No.	Picture	4 x 6	Extra 2 m	Extra 1 m
Triple corner connector dia. 54 mm (Φ) (120°)	В1		2		
Triple corner connector dia. 54 mm (Φ) (120°)	B2		2		
Quad side connector dia. 54 mm (Φ) (120°)	ВЗ		4	2	2
Triple peak roof connector dia. 54 mm (Φ (120°)	B4		2		
Quad peak roof connector dia. 54 mm (Φ) (120 <sup>0</sup> )	B5		2	1	1
Tube dia. 50 mm (Φ) (990 mm)	41	•	16	4	4
Roof vertical bracing dia. 25 mm (Φ) (545 mm)	42		4	1	1
Roof horizontal bracing dia. 25 mm (Φ) (1130 mm)	43		4	1	1
Horizontal roof bracing dia. 25 mm (Φ) (1076 mm)	44		4	1	1
Tube dia. 38 mm (Φ) (840 mm)	45	•	4		
Rura dia. 50 mm (Φ) (935 mm)	46	•	4		

# type **P50**


Name	No.	List of additional parts	
Lifting tube: 0,5 m height	19		
Lifting tube: 1 m height	20	• •	
Reinforcement	21		
Side cross cable, height: 2m	22		
Side cross cable, height: 2,5m	23		
Side cross cable, height: 3m	24		
Side cross cable, height: 3,5m	25		
Side cross cable, height: 4m	26		
horizontal pipe (2 m) for the FR cover	27	•	
horizontal pipe (2 m) for the FR cover	28	•	
horizontal pipe (1 m) for the FR cover	29	•	
Horizontal pipe inserted into FR cover (2 m)	30		
Horizontal pipe inserted into FR cover (1 m)	31		
Horizontal reinforcements for entrances width: 5m	57		
Horizontal reinforcements for entrances width: 6m	67		
Horizontal reinforcements for entrances width: 8m	87		
Roof cross cable for 4m width	48		
Roofs cross cable for 5m width	58		
Roofs cross cable for 6m width	68		
Roofs cross cable for 8m width	88		

#### STEP 1

The tent should be deployed on the flat surface.


#### For the tents with the even length of the side eg.: 8m, 10m, 12m, 20m, 30m, .....

Distribute the parts as pictured below. The connectors's (5) longer side should be facing the connector (B3). Assemble all the tubes dia. 50 mm ( $\Phi$ ) (2) tubes with the connectors using the M8x70 screws. Tubes dia. 38 mm ( $\Phi$ ) (41) should be assembled with the M8x50 screws.



### For the tents with the uneven length of the side eg.: 9m, 11m, 13m, 21m, 31m.....

Distribute the parts as pictured below. The connectors's (5) longer side should be facing the connector (B3). Assemble all the dia. 50 mm ( $\Phi$ ) (2) tubes with the connectors using the M8x70 screws. Tubes dia. 38 mm ( $\Phi$ ) (41) should be assembled with the M8x50 screws.



The extension tube should be located in the second section.

**B2** 


В1

44

43

В2

## STEP 2/a



**B3** 

В3

B2

⚠ The tent with the roof pulls (optional)





Table of	parts for the h	eights:
Heights	Parts	
2m	no. 1	(Picture no. 1)
2,5m	no. 1 + no.19	(Picture no. 2)
3m	no. 1 + no20	(Picture no. 2)


Table of	parts for the heights:
Heights	Parts
3,5m	no.1 + no.20 + no.19 (Picture no.3)
4m	no.1 + no.20 + no.20 (Picture no. 3)

Gently lift the tent on one side and mount the tubes (1). The three symmetrical holes in the tube should be facing downwards. Next, lift the tent on the other side and repeat the action.




### 

Lift the tent with the tubes installed on the one side and mount the 0,5 m lifting tubes (19) for the tent height 2,5m, or 1 m lifting tubes (20) for the tent 3 m height. Then, lift the tent on the other side and repeat the action.




### STEP 3/b A For the 3,5 or 4m height.

Lift the tent with the lifting tubes (19 or 20) installed on the one side; next, mount the 0,5 m lifting tubes (19) or 1 m lifting tubes (20). Then, lift the tent on the other side and repeat the action.




#### STEP 4

Mount diagonally the corner feet (6), and next the feet (7) to the construction of the tent. On the side of the construction mount feet (8) and connect them to the tubes (2). For the tents with the uneven side length, mount the extension in the third section. Next install the feet (9) on the back and the front; connect them with the corner feet using the tube (45). All the feet should be mounted securely to the ground.




#### STEP 5

Connect the tubes (1) and (46). These elements should be mounted to the entrance feet (9) and the connector (4). The connection with the connectors (4) should be on the inside of the tent.




## Tent with the side pulls. (optional)

On the both sides of the tent install the side pulls every two sections. The pulls should cross in the middle. Mount the pulls starting from the connector (B1) and feet (7). All the pulls should be mounted on the outer side of the construction.




# ⚠ Tent with the single reinforcements - Polar (optional)

The reinforcement (21) should be connected to the vertical pipe (1) and roof pipe (41).




# ⚠ Tent with the double reinforcements - Polar Plus (optional)


Two reinforcements (21) should be connected to the vertical pipe (1) and roof pipe (41).



# Tent with the single reinforcements - Polar (optional)



## Tent with the double reinforcements - Polar Plus (optional)




#### STEP 6


For the tents with the side panels height 2 m mount the panels with the drainage apron facing downwards.

For the tents with the side panels height above 2 m you need to connect the basic panel with the lifting panel(s).


0,5m



ide 2m Side 2,5m




0,5m
1m
2m
Side 3,5m



Assembled panels are ready to be mounted using the velcros on the roof. In order to fix the panels on the sides the elastic rubber with the ball should be used.







The metal loops and elastic rubber with ball are required to fix the entrance on the both sides of the tent. Install the top to the vertical tube (bracings 43 and 44 put together) using the metal loops. Fix the sides using the elastic rubbers with the balls.

Attach the masking stripes. If the tent's side panel's height is above 2 m, connect the masking stripes like the side panels (see the picture below). Four wider masking stripes should be fixed on the sides of the tent.

