Tent installation instructions

Tent 5m type P50

Name	No.	Picture	5 x 6	Extra 2 m	Extra 1 m
Tube dia. 50 mm (Φ) (1890 mm)	1	• • •	12	2	2
Tube dia. 38 mm (Φ) (1920 mm)	2	• • • •	21	7	
Tube dia. 38 mm (Φ) (930 mm)	3	•			7
Triple roof connector dia. 54 mm (Φ)	4		4		
Quad roof connector dia. 54 mm (Φ)	5		4	2	2
Corner foot	6		2		
Corner foot	7	ST.	2		
Foot	8		4	2	2
Entrance foot	9		4		
Roof bracing dia. 25 mm (Φ) (320mm)	10		4	1	1
Peg 8x300mm	11	©}	4		
Peg 6x180mm	12		12	2	2
Peg 4x180mm	13		42	6	6
Rope	14		4		
Screw M6x35	15		9	2	2
Screw M8x50	16		50	10	10
Screw M8x70	17		62	12	12
Loop to mount the entrance	18	\bigcirc	16		

Tent installation instructions

Tent 5m type P50

Name	No.	Picture	5 x 6	Extra 2 m	Extra 1 m
Triple corner connector dia. 54 mm (Φ) (110 ^o)	A1	de	2		
Triple corner connector dia. 54 mm (Φ) (110 ⁰)	A2		2		
Quad side connector dia. 54 mm (Φ) (110 ^o)	A3	×	4	2	2
Triple peak roof connector dia. 54 mm (Φ) (140 ⁰)	A4		2		
Quad peak roof connector dia. 54 mm (Φ) (140 ⁰)	A5		3	1	1
Tube dia. 50 mm (Φ) (1165 mm)	51	• • • •	16	4	4
Roof vertical bracing dia. 25 mm (Φ) (418 mm)	52		4	1	1
Roof horizontal bracing dia. 25 mm (Φ) (1375 mm)	53		4	1	1
Horizontal roof bracing dia. 25 mm (Φ) (1326 mm)	54	e	4	1	1
Tube dia. 38 mm (Φ) (1080 mm)	55	•	4		
Tube dia. 50 mm (Φ) (700 mm)	56	•	4		

Tent installation instructions

type **P50**


Name	No.	List of additional parts
Lifting tube: 0,5 m height	19	••
Lifting tube: 1 m height	20	••
Reinforcement	21	
Side cross cable, height: 2 m	22	
Side cross cable, height: 2,5 m	23	
Side cross cable, height: 3 m	24	
Side cross cable, height: 3,5 m	25	
Side cross cable, height: 4 m	26	
horizontal pipe (2 m) for the FR cover	27	•
horizontal pipe (2 m) for the FR cover	28	•
horizontal pipe (1 m) for the FR cover	29	•
Horizontal pipe inserted into FR cover (2 m)	30	
Horizontal pipe inserted into FR cover (1 m)	31	
Horizontal reinforcements for entrances width: 5m	57	
Horizontal reinforcements for entrances width: 6m	67	
Horizontal reinforcements for entrances width: 8m	87	

Roof cross cable for width 4m	48	
Roofs cross cable for width 5m	58	
Roof cross cable for width 6m	68	
Roof cross cable for width 8m	88	

The tent should be deployed on the flat surface.


For the tents with the even length of the side eg.: 8m, 10m, 12m, 20m, 30m,

Distribute the parts as pictured below. The connectors's (5) longer side should be facing the connector (B3). Assemble all the dia. 50 mm (Φ) tubes (2) with the connectors using the M8x70 screws. The dia. 38 mm (Φ) tubes (51) should be assembled with the M8x50 screws.




For the tents with the uneven length of the side eg.: 9m, 11m, 13m, 21m, 31m.....

Distribute the parts as pictured below. The connectors's (5) longer side should be facing the connector (B3). Assemble all the dia. 50 mm (Φ) tubes (2) with the connectors using the M8x70 screws. The dia. 38 mm (Φ) tubes (51) should be assembled with the M8x50 screws.



STEP 2/a



\triangle The tent with the roof pulls (optional).

On the both sides of the tent mount the cross cables (68) every two sections. The cables should cross in the middle. Start with the connector (A4) and (A2). Every roof cable should be fixed above the roof construction.






Table of parts for the heights:			Table of parts for the heights:			
Heights	Parts		Heights	Parts		
2m	no.1	(Picture no.1)	3,5m	no.1 + no.20 + no.19	(Picture no.3)	
2,5m	no.1 + no.19	(Picture no.2)	4m	no.1 + no.20 + no.20	(Picture no.3)	
3m	no.1 + no.20	(Picture no.2)				

Gently lift the tent on one side and mount the pipes (1). The three symmetrical holes in the pipe should be facing downwards. Next, lift the tent on the other side and repeat the action.




Lift the tent with the tubes installed on the one side and mount the 0,5 m lifting tubes (19) for the tent height 2,5 m, or 1 m lifting tubes (20) for the tent height 3 m. Then, lift the tent on the other side and repeat.




STEP 3/b

\triangle For the 3,5 or 4m height.

Lift the tent with the lifting tubes (19) or (20), installed on the one side; next, mount the 0,5 m lifting tubes(19) or 1m lifting tubes (20). Then, lift the tent on the other side and repeat.




Mount diagonally the corner feet (6), and next, the feet (7) to the construction of the tent. On the side of the construction mount feet (8) and connect them to the tubes (2). For the tents with the uneven side length, mount the extension (3) in the third section. Next install the feet (9) on the back and the front; connect them with the corner feet using the tubee (55). All the feet should be mounted securely to the ground.




STEP 5

Connect the tubes (1) and (56). These elements should be mounted to the entrance feet (9) and the connectors (4). The connection with the connector (4) should be on the inside of the tent.




A Tent with the side pulls. (optional)

On the both sides of the tent install the side cross pulls every two sections. The cables should cross in the middle. Mount the pulls starting from the connector (A2) and foot (6) and from connector (A1) and feet (7) on the other side. All the pulls should be mounted on the outer side of the construction.




A For the tents above 2m height (Polar plus)(optional)




A Tent with the single reinforcements - Polar (optional)


Connect the reinforcement (21) with the vertical tube (1) and the roof tube (51).




Tent with the double reinforcements - Polar Plus (optional) \wedge

Two reinforcements (21) should be connected to the vertical tube (1), and roof tube (51).






The side reinforcement (21) should be connected to the vertical pipe (1) and horizontal pipe (2). The reinforcements should be placed on the inside of the tent.



▲ Tent with the double reinforcements - Polar Plus (optional)


Two reinforcements (21) should be connected to the vertical tube (1) and horizontal tube (2). The reinforcements should be mounted on the either inside and outside sides or tubes (1) and (2).




For the tents with the side panels height 2 m mount the panels with the drainage apron facing downwards.

For the tents with the side panels height above 2 m you need to connect the basic panel with the lifting panel(s).









Side 3m

1 m





Side 3,5m



Side 4m

Assembled panels are ready to be mounted using the velcros on the roof. In order to fix the panels on the sides the elastic rubber with the ball should be used.





Metal loops and elastic rubber with ball are required to mount the entrance on the both sides of the tent. Install the top to the vertical pipe (18). Install the top to the vertical tube (53 and 54 put together) using the metal loops. Fix the sides using the elastic rubbers with the balls.

Attach the masking stripes. If the tent's side panel's height is above 2 m, connect the masking stripes like the side panels (see the picture below). Each of the four wider masking stripes should be fixed on each side of the tent.

