Tent 4m type Sp38

Name	No.	Picture	4 x 4	Extra 2 m	Extra 1 m
Pipe dia. 38 mm (Φ) (1895 mm)	1		6	2	2
Pipe dia. 38 mm (Φ) (1930 mm)	2	•	18	7	
Pipe dia. 38 mm (Φ) (930mm)	3				7
Triple roof connector dia. 42 mm (Φ)	4		4		
Quad roof connector dia. 42 mm (Φ)	5		2	2	2
Corner foot	6		2		
Corner foot	7	38	2		
Foot	8		2	2	2
Entrance foot	9		2		
roof concentration dia. 25 mm (Φ) (320 mm)	10		3	1	1
Peg 8x300mm	11	©—————————————————————————————————————	4		
Peg 6x180mm	12		6	2	2
Peg 4x180mm	13		36	6	6
String	14		4		
Screw M6x35	15		6	2	2
Screw M6x50	16		74	28	28
Entrance mounting bracket	18		12		

Tent 4m type Sp38


		rent -in type opoc			
Name	No.	Picture	4 x 4	Extra 2 m	Extra 1 m
Triple connector 42 mm (Φ) (120°)	A1		6		
Quad connector 42 mm (Φ) (120°)	A2		3	3	3
Vertical roof connector dia. 25 mm (Φ) (507 mm)	40		3	1	1
Horizontal roof connector dia. 25 mm (Φ)	41		3	1	1
Horizontal roof connector dia. 25 mm (Φ)	42		4	1	1
Tube dia. 38 mm (Φ) (1185 mm)	43	•	12	4	4

STEP 1

The tent should be deployed on the flat surface.


For the tents with the even length of the side eg. 8m, 10m, 12m, 20m, 30m,

Distribute the parts as pictured below. Connect all the dia. 38 mm (Φ) tubes with the connectors using the M6x50 screws.




For the tents with the uneven length of the side eg. 9m, 11m, 13m, 21m, 31m.....

Distribute the parts as pictured below. Connect all the dia. 38 mm (Φ) tubes with the connectors using the M6x50 screws.




The extension tube should be located in the third section.

STEP 2/a



Connect the brackets (41) and (42) using the M6x35 screws. Connect the obtained construction to the lower part of connectors (4 or 5).

Using the vertical bracket (40) connect the horizontal bracket (10) to the previously assembled parts.




Fully assembled roof construction should look like on the picture above.

Gently lift the tent on one side and mount the pipe (1). The single hole in the pipe should be facing downwards. Next, lift the tent on the other side and mount the pipe (1) there.





STEP 4


Mount the corner feet (6) diagonally (same applies to feet 7). On the sides of the tent mount the feet (8) and connect them to the tubes (2). For the tents with uneven length of the side, the 1 meter extension (3) should be mounted in the third section. The feet (9) should be installed on the front and on the back of the construction and connected to the corner feet via tube (2). All the feet should be securely mounted to the ground.



Side panels should be mounted directly to the roof using the velcro stripes. Sides of the panels should be mounted using the elastic rubber with the ball.







Fix the roof pulls on the corners of the tent using the (14) and (11) parts. All the lines should be tight.